Date & Time

Configure the system date and time of your network drive.

Changing the date and the time may interrupt some of the services that rely on date & time. If possible, finish all file transfers and downloads before you change these settings.

Date & Time



Field	Description
Date	Set the server date by selecting the date in the calendar.
Time	Enter the system time in **hours:minutes:seconds** (e.g. 13:15:07).
Apply	Apply and save the changes.

Time Zone

To set the time by time zone, select the city closest to your home from the list of available cities and

then click **Apply**.



Internet Time

Select one of the time servers from the list and then click **Apply** to synchronize the time over the internet.



From:
http://wiki.myakitio.com/ - **MyAkitio Wiki**

Permanent link:
http://wiki.myakitio.com/system_date_time

Last update: **2012/10/26 13:17**