


# Date & Time

Configure the system date and time of your network drive.



Changing the date and the time may interrupt some of the services that rely on date & time. If possible, finish all file transfers and downloads before you change these settings.

## Date & Time




| Field        | Description  |
|--------------|--|
| <b>Date</b>  | Set the server date by selecting the date in the calendar.             |
| <b>Time</b>  | Enter the system time in <b>hours:minutes:seconds</b> (e.g. 13:15:07). |
| <b>Apply</b> | Apply and save the changes.  |

## Time Zone


To set the time by time zone, select the city closest to your home from the list of available cities and

then click **Apply**.



## Internet Time

Select one of the time servers from the list and then click **Apply** to synchronize the time over the internet.



From:  
<http://wiki.myakitio.com/> - **MyAkitio Wiki**

Permanent link:  
[http://wiki.myakitio.com/system\\_date\\_time](http://wiki.myakitio.com/system_date_time)

Last update: **2012/10/26 13:17**

